





**POWER BOARD PD0755A-1**  
BOTTOM (FOIL) SIDE




**IF/AV BOARD PD0755A-2**  
BOTTOM (FOIL) SIDE




**CONTROL BOARD PD0755A-4 LED BOARD PD0755A-3**  
BOTTOM (FOIL) SIDE









35WP26P  
POWER-POWER  
[SHEET-1/3]

A

B

C

D

E

F

A


B

C

D


E

F



35WP26P  
POWER-IF RIGHT SIDE AV  
[SHEET-2/3]





35WP26P  
POWER-IF RIGHT SIDE AV  
[SHEET-2/3]

Outer GND Area

POWER SA01 POS UP SA02 POS DN SA03 VOL UP SA04 VOL DN SA05 VIDEO SA06 MENU SA07

PUSH SW 1C1P DC12V 005A

RA73 1/6P10k RA72 1/6P22k RA71 1/6P68k RA75 1/6P22k RA74 1/6P10k

773

4 3 2 1

PA01B PLUG 4P

Signal GND GND KEY B KEY A

TO SIGNAL(MICON)

MA01

[illegible]



1 2 3 4

A

B


C

D


E

F

# CONTROL



LED



35WP26P  
POWER-LED/CONTROL  
[SHEET-3/3]